

## Snom Quick Reference Guide

### Transfer a call

During a call:

Unattended transfer: Press **TRANSFER** and dial relevant extension number and press ✓, then hang-up.

Attended Transfer: Press **Line 2** and dial relevant extension number and press ✓, announce caller then press **TRANSFERx2**.

### Call Pick Up

When pickup groups are programmed by the technician you can pick up any extension in your own group

Dial **0\*** lift handset / press ✓

### Call Pick Up Select

Only the Operator can do a Direct call pickup.

Dial **0\* ext no** lift handset / press ✓

### Call Forward / Divert

To set:

Dial **720**, destination number, lift handset / press ✓, dial ext pin (e.g. 1234) ✓.

To cancel:

Dial **721**, lift handset / press ✓, dial ext pin, ✓.

### Follow me

To set:

Dial **715** destination ext number, lift handset / press ✓, dial ext pin, ✓.

To cancel:

Dial **718**, lift handset / press ✓, dial ext pin, ✓

### Call Park

During a call dial **55**, the system will read back park number

To **retrieve**, dial **55**, dial **park number (e.g. 101)** lift handset / ✓

### Conference Call

Dial first party, dial **20\***, end call.  
 Dial second party, dial **20\***, end call.  
 Dial third party, dial **20\***, end call.  
 Dial fourth party, dial **20\***, end call.  
 Dial fifth party, dial **20\***, all in conference.

Only 5 party conference.

### Account Code

Dial: 41 number  
 lift handset / press ✓  
 After beep enter **account code**, press ✓.  
 (Account codes must be programmed by the technician)

### Extension Pin

*Default is 1234*  
 To change Dial **110\***, lift handset / press ✓,  
 Dial old pin, Dial new pin, #

### Lock Phone

To Lock:  
 Dial **77**, lift handset / press ✓, **ext pin**, ✓.

To Unlock:  
 Dial **77**, lift handset / press ✓, **ext pin**, ✓.

### Time / Mode Service

To activate dial:

781 – Day Mode  
 782 – Lunch Mode  
 783 – Night Mode  
 784 – Break Mode

lift handset / press ✓

### Barge in

Barge **92** ext  
 Whisper **91** ext  
 Spy **90** ext

Dial **9X**, extension number, lift handset / press ✓

### Speed Dial Numbers

#### Personal

To program:

Dial **2\* code (0-9) \*** number, lift handset / press ✓

To use:

Dial **3\* code (0-9)** lift handset / press ✓

#### System

To program:

Dial **7\* code (00-99) \*** number, lift handset / press ✓

To use:

Dial **\* code (00-99)** lift handset / press ✓  
 (*Speed dials can also be programmed by the technician.*)

### Voicemail

Dial **\*100#**  
 Lift handset /press ✓, follow voice prompts.